

GLOGGLES™

Switch from **GLASSES** to **GOGGLES** with a simple push, pull and snap!



- High-impact polycarbonate lens
- 99.9% UV protection
- Anti-fog coating on lens
- Scratch resistant coating
- Foam padding forms a snug fit
- Includes goggle strap and eyeglass temples for easy interchangeability
- Meets **ANSI** Z87.1 – 2015

**Poly Bag
Item No.**
5103
5103-01
5103-02

Lens Color
Clear
Gray
Yellow

Clear



Gray



Yellow



Classic Style



- Impact resistant polycarbonate lenses
- 99.9% UV protection
- Lightweight comfort
- Meets ANSI Z87.1 – 2015

Poly Bag

Item No.
5125

Lens Color
Clear

Worker Bees



- Impact polycarbonate lens
- 99.9% UV protection
- Scratch resistant coating
- Ideal visitor specs
- Fits over most prescription glasses
- Meets ANSI Z87.1 – 2015

Poly Bag

Item No.
5120

Lens Color
Clear

Visitor Specs



- Impact polycarbonate lens
- 99.9% UV protection
- Economical safety glasses for visitors
- Fits over most prescription glasses
- Meets ANSI Z87.1 – 2015

Poly Bag

Item No.
5210

Lens Color
Clear

SAFETY GLASSES LENS COLOR GUIDE

What color of lens is the right one for you? Use this guide to help you choose. A rule of thumb is to use contrasting colors to decide what lens color meets your needs. For example; blue and yellow are contrasting colors, therefore a yellow light will absorb blue and ultraviolet lights and vice versa.

Clear Safety Glasses

Specifically designed for indoor protection where impact protection is required.

Gray Safety Glasses

Ideal for outdoor protection where light and glare can cause eye strain and fatigue. Gray lenses do not affect color recognition.

Indoor/Outdoor Safety Glasses

A clear lens with a slight mirror coating serves the same purpose as a gray lens, yet allows more visible light to pass through the lens making this lens ideal for indoor and outdoor use. This lens also reduces glare from artificial light.

Gold, Blue and Silver Mirror Safety Glasses

The “mirror” coating reflects and reduces the amount of light that passes through making these lenses ideal for outdoor where sunlight and glare cause eye strain and fatigue.

Yellow/Amber Safety Glasses

Ideal for creating maximum contrast, even in low light they block the blue portion of the visible light spectrum.

Filter Shades Safety Glasses

Ideal for protection against ultraviolet and infrared radiation; designed specifically for working with molten metal and welding operations.

Shade	Purpose
Shades 1.5 - 3	Torch Soldering
Shades 3 - 4	Torch Blazing
Shades 3 - 6	Cutting
Shades 4 - 8	Gas Welding
Shades 10 - 14	Electric Arc Welding



Clear Lens



Yellow Lens



Gray Lens



Indoor/Outdoor Lens

ZION X™



- High-impact polycarbonate lens
- 99.9% UV protection
- Anti-fog coating on lens
- Scratch resistant coating
- Indirect ventilated rubber seal
- Adjustable elastic fabric 1" head strap
- Meets ANSI Z87.1 – 2015

Poly Bag Item No.
 5104-01
 5104-02
 5104-03
 5104-04

Lens Color
 Clear
 Gray
 Yellow
 Mirror



Clear



Gray



Yellow



Mirror



Peel-Off Lens Covers Available



Deluxe Goggles



- Impact resistant polycarbonate lens
- 99.9% UV protection
- Anti-fog coating on lens
- Anti-splash: special vents prevent liquid from getting into eyes
- Sport-style design with 1.5" wide elastic headstrap
- Flexible PVC construction
- Meets ANSI Z87.1 – 2015

Clamshell

Item No.	Description
5106	Safety goggle
5106-10	Peel-off lens covers pack of 10

Overspray Goggles



- Impact resistant polycarbonate lens
- 99.9% UV protection
- Anti-fog coating on lens
- Anti-splash: special vents prevent liquid from getting into eyes
- Flexible PVC construction
- Meets ANSI Z87.1 – 2015

Clamshell

Item No.	Description
5110	Safety goggle
5111	Peel-off lens covers pack of 10



Chemical-Splash Goggles



- Impact resistant polycarbonate lens
- 99.9% UV protection
- Anti-splash: special vents prevent liquid from getting into eyes
- Flexible PVC construction
- Meets ANSI Z87.1 – 2015

Poly Bag

Item No.	Description
5109	Safety goggle



Standard Goggles



- Impact resistant polycarbonate lens
- 99.9% UV protection
- Flexible PVC construction
- Economical eye protection
- Meets ANSI Z87.1 – 2015

Poly Bag

Item No.	Description
5101	Safety goggle